

Fitting Instructions

Revo Carbon Intake 3.0 TFSI B9 S4/S5 (8W/F5)

Fitting Difficulty



Contents


Description	Qty
Revo Intake Silicone Hose	1
Revo Carbon Series Air Box Lid	1
Revo Air Filter	1
120-140mm Hose Clamp	1
90-110mm Hose Clamp	1
60-80mm Hose Clamp	1

Recommended Tools

Tools	Size
Sockets	7mm
Ratchet	
Ratchet Extension	
Torx Bits	T25, T30



Before starting, please ensure that the engine is cool. Engine temperatures can remain high for a substantial amount of time after use.



Fitting Instructions

Revo Carbon Intake 3.0 TFSI B9 S4/S5 (8W/F5)

Fitting Difficulty



Installation was performed on a UK-spec. B9 S4. Installation on other vehicles will be similar but may not be exact.

- 1 Release bonnet and raise. Remove bonnet release handle from the slam panel by pressing in the release catch at the 12 o'clock position.


Note: do not close bonnet without refitting the release handle.



- 2 Remove the slam panel by unclipping along the front edge and then sliding it out from under the front air scoop.



- 3 Remove the 2 x T25 bolts from the intake ducting.



- 4 Unclip the intake ducting along the front edge and pull free from the airbox.



Fitting Instructions

Revo Carbon Intake 3.0 TFSI B9 S4/S5 (8W/F5)

Fitting Difficulty



- 5 Using a 7mm socket, loosen the 2 x hose clamps on the intake hose where it enters the airbox and connects to the intake hard pipe and remove the hose from the vehicle.



- 6 With the intake hose removed, the stock airbox lid can be removed by unscrewing the 6 x T25 screws from the top. Lift the lid out but keep the screws for the Revo lid.



- 7 Take the new Revo filter element and secure it to the Revo Carbon airbox lid with the supplied hose clamp.



- 8 Install the new Revo carbon lid with filter to the airbox base on the car, re-using the 6 x T25 screws you removed earlier. Be careful not to over tighten the screws on the carbon, they only need to just nip.



Fitting Instructions

Fitting Difficulty



Revo Carbon Intake 3.0 TFSI B9 S4/S5 (8W/F5)

- 9 Fit the Revo intake silicone using the supplied 100-120 and 60-80 hose clamps and be sure the Revo silicone sits flush against the intake pipe and airbox lid, tighten the 2 x supplied hose clamps to 3Nm.



- 10 Refit all OE parts back to vehicle. Reinstallation is the reverse of removal. Follow any factory torque specification during reinstallation of OE parts. **Check the bonnet release handle is refitted.** Check all sensors are reconnected. Test drive the vehicle to ensure no leaks/part interference during operation. Your installation is now complete.

Fitting Instructions

Revo Carbon Intake 3.0 TFSI B9 S4/S5 (8W/F5)

Fitting Difficulty



NO.	DESCRIPTION	QTY.
1	B9 S4/S5 Carbon intake lid	1
2	B9 S4/S5 Intake filter	1
	Hose clamp 120-140 (comes with filter)	1
3	B9 S4/S5 Carbon intake lid silicone	1
4	Hose clamp 90-110	1
5	60-80 Hose clamp S/S	1
6	Revo tag	1
7	Packaging - Turbo box	1

SCALE: 1:4

SHEET 1 OF 1

REV

02

revo

TITLE: RA841M200200 Working Instructions

SIZE: A

DWG. NO.: