

Fitting Instructions

Revo Intake Upgrade Kit VAG 2.0/1.8 TSI Transverse Mount

Fitting Difficulty



Dealer Fit Recommended

Contents

Description	Quantity
Revo Intake Pipe	1
Revo Intake Hose	1
Revo Coupler Hose	1
Revo Air Filter	1
Revo Heatshield	1
Mini Bracket Assembly	1
Filter Support Bracket	1
Heatshield Bracket	2
90-110 Hose Clamp	1
80-100 Hose Clamp	3
M6x20 Hex Head Bolt	3
M6 Nylock Nut	2
M6 Washer	5

Recommended Tools

Tools	Size
Ratchet	
Extension	
Socket	
Torx Bits	
Hex Key	
Constant Tension Pliers	



Before starting, please ensure that the engine is cool and the battery is disconnected. Engine temperatures can remain high for a substantial amount of time after use.



Fitting Instructions

Revo Intake Upgrade Kit VAG 2.0/1.8 TSI Transverse Mount

Fitting Difficulty



Dealer Fit Recommended

- 1 Undo the 2 x torx bolts (A). Unclip pipe (B) from air intake (C). Remove air intake from the vehicle.



- 2 Disconnect the air flow sensor (A). Release hose clamp (B) and pull the intake pipe from the air flow sensor housing.



- 3 Loosen bolt (A) and pull the airbox assembly upwards to release from the rubber mountings.



- 4 Release hose clamp (A) and remove the intake pipe from the turbo.



- 5 Remove the breather pipe (B) from the intake pipe.



- 6 Remove the retaining screw (A) and remove the intake pipe from the vehicle.



Fitting Instructions

Revo Intake Upgrade Kit VAG 2.0/1.8 TSI Transverse Mount

Fitting Difficulty



Dealer Fit Recommended

- 7 Remove the 2 x screws (A) and remove the air flow sensor from the OE airbox.



- 8 Assemble the heatshield brackets using the supplied hardware. Place the Revo intake hose into the assembled Revo heatshield, as shown.



- 9 Remove the OE battery carrier bolt (A). Install the Revo heatshield and Revo hose in the location of the OE airbox. Secure the back of the Revo heatshield using the OE battery carrier bolt (A), and at the OE airbox fixing using the hardware supplied (C). Secure the front of the heatshield using the OE torx bolt (B).



Fitting Instructions

Revo Intake Upgrade Kit VAG 2.0/1.8 TSI Transverse Mount

Fitting Difficulty



Dealer Fit Recommended

10 Install the Revo intake pipe onto the turbo coupler hose (A) and M6 mounting bolt (B). Fit the air flow sensor (C) onto the Revo intake pipe using the Revo flexible joiner hose and 2 x 80-100 hose clamps. Install the air flow sensor into the intake hose using 80-100 hose clamp. Note: the orientation of the air flow sensor should be the same as OE installation.



11 Install the Revo air filter into the intake hose with the 90-110 hose clamp. Note: ensure the hose clamp loops over the bracket inside the heatshield. Reconnect the air flow sensor. Check for correct alignment and tighten all hose clamps.



12 Check all hose clamps and that everything is attached and tightened correctly. Test drive to ensure the vehicle performs correctly and there are no leaks/part interference during operation. Your installation is now complete!

