

Fitting Instructions

2.0/1.8 TSI MQB Turbo muffler delete kit

Fitting Difficulty



Contents

Description	
Muffler delete	1
Silicone gasket	1

Recommended Tools

Tools	Size
Wrench	n/a
Socket	7mm
Allen key/bit	6mm



Before starting, please ensure that the battery is disconnected and you have ensured the engine is cool. Engine temperatures can remain high for a substantial amount of time after use.



Fitting Instructions

Fitting Difficulty



2.0/1.8 TSI MQB Turbo muffler delete kit

- 1 First, remove your airbox by loosening the hose clamp securing the pipe to the turbo, then **pull** up on the airbox to remove from vehicle. Picture A is for 2.0/1.8 TSI Golf platform and picture B is for the Polo/S1 platform.



- 2 Next, loosen the hose clamp securing the charge pipe hose to the turbo and move so you can get to the muffler.



- 3 Remove the three bolts on the muffler and then remove the OE part from the turbo.



- 4 Install the new Revo turbo muffler delete by first inserting the silicone gasket so that it sits flush **with** the base of the turbo muffler **Note: THIS MUST BE SAT FLUSH IN THE BASE, MAKE SURE YOU DO NOT PUSH INTO THE TURBO OUTLET!** Next, install the Revo muffler delete using the bolts you removed from the OE unit. Tighten so everything is secure and then re-assemble the charge pipe and airbox in the reverse of the removal. Ensure all parts are bolt tightened securely

